

FLEXIBLE SHOWER SEAL TAPE



Larsen Flexible Shower Seal Tape is a self-adhesive, high performance waterproof sealing tape that can be applied directly to the wall-facing edge of shower trays, baths or worktops. Used prior to installation, Flexible Shower Seal Tape provides a secure watertight seal.

QUICK & EASY
EASY TO USE
FAST INSTALLATION
SUITABLE FOR SHOWERS, BATHROOMS & KITCHENS



TECHNICAL INFORMATION

PRODUCT INFORMATION	
FORM:	Self-adhesive tape
COLOUR:	YELLOW
HAZARD INFORMATION:	No significant Hazard
CLEANING:	Clean tools, equipment etc. using white spirit.
PACKAGING:	3.6m and 25m rolls
STORAGE CONDITIONS:	Store in sealed containers in dry conditions, protected from extremes of temperature
SHELF LIFE:	Minimum 24 months in unopened manufacturer's packaging
APPLICATION INFORMATION	
WEIGHT:	Approx. 60g/m
THICKNESS:	0.70 mm
EXTENSION AT BREAK	Longitudinal – 70% Lateral – 335% (sealing tape)
BREAKING LOAD:	Longitudinal – 104N/15mm Lateral – 23N/15m (sealing tape)
APPLICATION TEMPERATURE:	+5°C to +30°C
TEMP RESISTANCE:	-5°C to +60°C
BURSTING PRESSURE:	2.0 bar
PEEL STRENGTH (PVC)	>6.5N/20mm (butyl strip)

DIRECTIONS FOR USE

PREPARATION

Substrate should be structurally sound & stable. It should be suitably cured, dry, free from dust and all contamination that may affect bond. New shower trays or baths etc, may require the use of a suitable detergent for cleaning and degreasing. Ensure surface is dry before application.

APPLICATION

Supplied ready for use.

Unroll the tape, place it on a solid base and trim to the required length. The tape should be installed in one piece avoiding seams.

Place the tape at one end of the bath or shower tray with the bigger part of the tape facing up and the butyl strip (grey) facing the bath or shower tray. Partially remove the backing from the butyl strip and begin pressing tightly to the edge of the bath or tray.

Keeping the tape tight and pressing down firmly to help it to bond and to prevent bubbles or creases forming, continue to remove the remaining protective film. A wallpaper seam roller is useful in larger areas and to ensure tape is fully adhered.

Position the bath, tray etc against the wall and bond the top part of the tape to the wall with a suitable product (Larsen F1X, Larsen Tanking membrane or suitable Larsen cement based tile adhesive).

Apply subsequent tanking membrane or sheets to the wall overlapping the Flexible Shower Seal Tape.

Tiling can then be completed as normal.

RESTRICTIONS

Temperature - Minimum 5°C during application. Adhesive strip will be stiffer in cold temperatures and softer in warm conditions. Substrates must be suitable for the tiling application. It is not recommended for use on substrates which are not sufficiently strong or suitable to receive the finish, for example painted walls are not suitable to receive tiling. Pay particular attention to corners – do not cut and ensure there are no creases. Do not allow silicone sealant to come in contact with the butyl adhesive strip. Not suitable for application over soft bituminous materials, oils, grease etc. If in doubt, contact our Technical Department.

